
V1.7

Unit:mm



Installation Manual:

- 2 \parallel The tube for connecting vice-machine to master machine in the same lane (CAT5 network cables*2PCS, 2 * 0.5mm motor line*1PCS).
- 3 \parallel TCP/IP ethernet cable for connecting access device to PC.
- 4 Control board.

5 Fixing the equipment with M12 X 100mm expansive bolt.

Mark: All wires extending out of the ground shall be no less than 2M.